

Thank you for your order!

We appreciate your business. Additional information on your product may be available on our website.



Happy?

Wonderful! We are very glad. Please share your experience with us and others. It helps us know what you like best!

- Review this product at www.householdessential.com.

Search the item # from the home page to find the product. Leave your review under the review tab on the product's page!

- Follow us on Facebook and Instagram!

Customer Service

1-800-922-5524 | 1-314-428-5657
info@householdessential.com

Open Mon-Fri at 8:30 am CT.
Closed all national holidays.




©2017 HOUSEHOLD ESSENTIALS, LLC
Hazelwood, MO 63042
www.householdessential.com

3-Shelf Utility Cart 05121 | White




Parts

Ax2
End Frame



Bx3
Storage Baskets




Cx4
Casters




Assembly

- 1 Attach (1) non-locking caster (C) into each end frame assembly (A).



Assembly con't

- 2 **NOTE:** Start assembling the rack with the bottom shelf first and work your way to the top.



- 3 Top 2 hooks on basket (B), hook over top wire on frame (A).
Bottom 3 hooks on basket (B), hook over bottom wire on frame (A).

