

# Thank you for your order!

We appreciate your business. Additional information on your product may be available on our website.



Happy?

Wonderful! We are very glad. Please share your experience with us and others. It helps us know what you like best!

- Review this product at [www.householdessential.com](http://www.householdessential.com).

Search the item # from the home page to find the product. Leave your review under the review tab on the product's page!

- Follow us on Facebook and Instagram!

## Customer Service

1-800-922-5524 | 1-314-428-5657  
[info@householdessential.com](mailto:info@householdessential.com)

Open Mon-Fri at 8:30 am CT.  
Closed all national holidays.



©2019 HOUSEHOLD ESSENTIALS, LLC  
Hazelwood, MO 63042  
[www.householdessential.com](http://www.householdessential.com)



Not happy?


Please give our St. Louis customer service a call at 1-800-922-5524. We are here to help.

- Missing parts?
- Having trouble with assembly?

# Cabinet Hamper Seat 18410-1




## Parts




**Ax1**  
Front Panel



**Bx1**  
Lid



**Cx1**  
Left Side Panel




**Dx1**  
Right Side Panel



**Ex1**  
Top Back Panel



**Fx1**  
Lower Cross Brace



**Gx1**  
Bottom Panel



**Hx1**  
Middle Back Panel



**Ix2**  
Hanging Bars



**Jx1**  
Cushion



**Kx1**  
Bag




**Qx2**  
Notched Bag Support



**Sx2**  
Seat Support

## Hardware Bag



**Lx10**  
Cam Bolt



**Mx10**  
Cam Lock



**Nx2**  
Pivot Hinge



**Ox8**  
Wood Dowels



**Px4**  
Self Tap Screws



**Rx4**  
Self Tap Screws



**Tx6**  
Self Tap Screws

## Assembly

**NOTE:** Finger tighten screws until fully assembled.

**1**




Diagram 1




Diagram 2





Diagram 3




Diagram 4

1. Screw cam bolts (L) into left and right side panels (C & D). Insert wood dowels (O) into right side panel (D). See diagram 1.
2. Attach seat support (S) into left and right side panels (C & D) using screws (T).
2. Lay front panel and back panels (A & E) face down and attach notched bag supports (Q) to panels with screws (P). Insert cam locks (M) into front panel (A). See diagram 2.
3. Insert cam locks (M) into top back panel (E) and lower cross brace (F). See diagram 3.
4. Insert short side of pivot hinge (N) into groove on lid (B). Secure with 2 self tapping screws (R). See diagram 4.

## Assembly con't

**2**

1. Align front panel (A), groove side down, to side panel (D). Turn cam locks to secure. Insert pivot hinge (N) into right side panel (D). See diagram 5.
2. Align top back panels (E & F) to side panel (D) with cam nuts to the back. Turn cam locks to secure. See diagram 6.
3. Slide middle back panel (H) into grooves in back panels (E and F). Slide floor panel (G) into grooves on front panel (A) and lower cross brace (F). See diagram 7.
6. Insert dowels (O). See diagram 8.
7. Place left side panel (C) onto assembly. Make sure panel aligns with cam bolts, hinges, and back and floor panels. Turn cam locks to secure. See in diagram 9.
8. Insert hanging bars (I) through top of bag (K). Lay into notches inside hamper bench. See diagram 10.
9. Place cushion (J) on top of lid. See in diagram 11.




Diagram 5




Diagram 6




Diagram 7




Diagram 8




Diagram 9




Diagram 10





Diagram 11