

Thank you for your order!

We appreciate your business. Additional information on your product may be available on our website.



Happy?

Wonderful! We are very glad. Please share your experience with us and others. It helps us know what you like best!

- Review this product at www.householdessential.com.

Search the item # from the home page to find the product. Leave your review under the review tab on the product's page!

- Follow us on Facebook and Instagram!

Customer Service

1-800-922-5524 | 1-314-428-5657
info@householdessential.com

Open Mon-Fri at 8:30 am CT.
Closed all national holidays.



©2019 HOUSEHOLD ESSENTIALS, LLC
Hazelwood, MO 63042
www.householdessential.com



Not happy?

Please give our St. Louis customer service a call at 1-800-922-5524. We are here to help.

- Missing parts?
- Having trouble with assembly?


Cedar Shoe Rack 2122-1



Parts

Ax4

Side Panel




Bx6

Cedar Slats (Dowels Attached)



Cx4

Dowels




Assembly

1

Assemble shoe racks individually, first.

Attach cedar slats (B) to side panels (A): 1 across the top and 2 flat to make the bottom.

Gently tap together with a rubber mallet.



Assembly con't

2

OPTIONAL: Join shoe racks together.

Place dowels (C) into top of shoe rack. Take second shoe rack and place on top of dowels to stack.

Gently tap together with a rubber mallet.

