

Thank you for your order!

We appreciate your business. Additional information on your product may be available on our website.



Happy?

Wonderful! We are very glad. Please share your experience with us and others. It helps us know what you like best!

- Review this product at www.householdessential.com.

Search the item # from the home page to find the product. Leave your review under the review tab on the product's page!

- Follow us on Facebook and Instagram!

Customer Service

1-800-922-5524 | 1-314-428-5657
info@householdessential.com

Open Mon-Fri at 8:30 am CT.
Closed all national holidays.



©2017 HOUSEHOLD ESSENTIALS, LLC
Hazelwood, MO 63042
www.householdessential.com



Not happy?

Please give our St. Louis customer service a call at 1-800-922-5524. We are here to help.

- Missing parts?
- Having trouble with assembly?

3 Tier Carousel

Shoe Tree

2130-1 (Silver)


2131 (Chrome)

2133-1 (Black)

2138 (Bronze)



Parts



Assembly


1 Slide Locking Washer (L) onto Screw (I), then slide Washer (J) onto Screw (I). Slide Base (E) onto Screw (I). Add second Washer (J). Place Base Cover (D) onto Screw (I).

2 Slide Bottom Tube (A) onto Screw (I). Hold Bottom Tube firmly and using Allen Wrench (K), tighten screw until snug.

3 Loosen screw on Clamp (G) and slide onto Bottom Tube (A). Slide Shoe Carousel (C) onto Bottom Tube (A).

4 Repeat Step 3.

***NOTE:** Washers (J) must be assembled one on top and one on the bottom of Base (E) or the unit will wobble.



Assembly con't

5 Push End Caps (F) firmly into holes on Handle (H).

6 Screw Handle (H) into Top Tube (B). Tighten until secure.

7 Slide Shoe Carousel (C) onto bottom of Top Tube (B). Slide Clamp (G) up to Shoe Carousel (C) and tighten screw.

8 Screw Top Tube (B) into Bottom Tube (A). Tighten until secure.

9 Slide each Shoe Carousel (C) to desired height and secure by sliding Clamp (G) up to Shoe Carousel (C) and tightening screw.

***NOTE:** Part "G" - Do not overtighten screw on sliding clamp. This may cause part to break.

